

# ADAPTER ÜBERSICHT

## F-SERIE



+ TRAGETASCHE



+ ZUSATZ-ADAPTER



Art.Nr. 60252  
MAXI-COSI\*



Art.Nr. 60251  
RÖMER I.SIZE

+ WANNE CF3



+ ZUSATZ-ADAPTER



Art.Nr. 60255  
MAXI-COSI\*



Art.Nr. 60257  
RÖMER I.SIZE

60269 BASIS-ADAPTER  
WANNE INKLUSIVE

## FX4 CLASSIC

60261 BASIS-ADAPTER  
SITZ INKLUSIVE



+ TRAGETASCHE



+ ZUSATZ-ADAPTER



Art.Nr. 60255  
MAXI-COSI\*



Art.Nr. 60257  
RÖMER I.SIZE

+ WANNE CX3



+ ZUSATZ-ADAPTER

60264 BASIS-ADAPTER  
WANNE INKLUSIVE



Art.Nr. 60271  
MAXI-COSI\*



Art.Nr. 60272  
RÖMER I.SIZE

+ WANNE RELAX



60263 BASIS-ADAPTER  
WANNE INKLUSIVE

## FX4 LIFE



+ WANNE CX3



+ ZUSATZ-ADAPTER

60264 BASIS-ADAPTER  
WANNE INKLUSIVE



Art.Nr. 60271  
MAXI-COSI\*



Art.Nr. 60272  
RÖMER I.SIZE

+ WANNE RELAX



60263 BASIS-ADAPTER  
WANNE INKLUSIVE

+ HÖHENADAPTER



Art.Nr. 60262

INDY



+ CLASSIC



60261 BASIS- ADAPTER  
SITZ **NICHT INKLUSIVE**

+ TRAGETASCHE



+ ZUSATZ-ADAPTER



Art.Nr. 60255  
MAXI-COSI\*



Art.Nr. 60257  
RÖMER I.SIZE

+ WANNE CX3

60264 BASIS-ADAPTER  
WANNE INKLUSIVE



+ ZUSATZ-ADAPTER



Art.Nr. 60271  
MAXI-COSI\*



Art.Nr. 60272  
RÖMER I.SIZE

+ WANNE RELAX

60263 BASIS-ADAPTER  
WANNE INKLUSIVE



INDY



+ LIFE



+ WANNE CX3  
60264 BASIS-ADAPTER  
WANNE INKLUSIVE



+ ZUSATZ-ADAPTER



Art.Nr. 60271  
MAXI-COSI\*



Art.Nr. 60272  
RÖMER I.SIZE

+ WANNE RELAX


60263 BASIS-ADAPTER  
WANNE INKLUSIVE



INDY



+ SPORT



+ WANNE CX3  
60264 BASIS-ADAPTER  
WANNE INKLUSIVE



+ ZUSATZ-ADAPTER



Art.Nr. 60271  
MAXI-COSI\*



Art.Nr. 60272  
RÖMER I.SIZE

+ WANNE RELAX

60263 BASIS-ADAPTER  
WANNE INKLUSIVE



SMILOO FUN INKL. RELAX



+ ZUSATZ-ADAPTER

60279 BASIS-ADAPTER  
SITZ INKLUSIVE

60263 BASIS-ADAPTER  
WANNE INKLUSIVE



Art.Nr. 60271  
MAXI-COSI\*



Art.Nr. 60272  
RÖMER I.SIZE